











Key	Component	Qty
	A Bleeding Valve Key	1
	B Bleeding Valve 1/2"	1
	C Threaded Screw Nest	2
	D Wall Mounting Bracket	2
	E Floor Mounting Bracket	2
	F Screw-8x12mm	2
	G Screw-5,5x45mm	4
	H Wall Plug	4
	I 1/2" Flexible Hose	2



Assembly Instructions

Fit Bleeding valve (B).

Use Carisa bleeding valve key (A) to turn bleeding valve (B) on final installation.

Assemble the threaded screw nests (C) on right and left top of the collector by using allen key.

Accurately set radiator position where the wall distance should be 20cm at bottom side and mark out bracket holes on wall and floor.

Drill two 8 mm holes on the wall for mounting brackets (D) and two 8mm holes on the floor for mounting brackets (E).

Screw brackets (D and E) into the wall plugs (H) with 5,5mm diameter x 45mm screws (G).

Fit the bottom side of the collector on the floor mounting brackets (E) and then justify the upper side to the wall mounting brackets (F) till centering the screw holes (C).

Fix wall mounting brackets (D) and radiator by using screw (F).

Assemble the 1/2" flexible hoses (I) on the threaded collector holes to use for (inlet/outlet) water connection.